

# **STEELCRAFT**

INSTALLATION INSTRUCTIONS  
**TAILLIGHT GUARD PART # 30260**  
2004 CHEVY COLORADO

## **PARTS LIST**

- (1)- TAILLIGHT GUARD PASSENGER SIDE
- (1)- TAILLIGHT GUARD DRIVER SIDE
- (2)- SUPPORT BRACKETS
- (2)- # 6 x 1/2" SCREWS, (8)- # 8 x 3/4" SELF TAPPING SCREWS

## **INSTALLING TAILLIGHT GUARD**

- 1) START WITH THE DRIVER SIDE, OPEN THE REAR LIFT GATE AND REMOVE THE SCREWS SECURING THE TAIL LIGHT TO THE BODY.
- 2) CAREFULLY UNSNAP THE TAIL LIGHT UNTIL IT IS FREED FROM THE HOUSING.
- 3) WHILE HOLDING THE TAIL LIGHT ASSEMBLY POSITION THE SUPPORT BRACKET TO THE INNER STUB , SNAP THE TAIL LIGHT ASSEMBLY BACK INTO BODY AND SECURE WITH THE SCREWS PREVIOUSLY REMOVED.
- 4) POSITION DRIVER SIDE TAILLIGHT GUARD IN CENTER OF TAIL LIGHT LENS WITH FORMED MOUNTING BRACKET TIGHT AGAINST INSIDE JAMB. WHILE HOLDING IN POSITION, MARK LOCATION OF HOLES IN BRACKET ONTO JAMB. (CENTER PUNCH WHERE MARKED)
- 5) DRILL WHERE MARKED USING DRILL BIT #7 BIT. ATTACH TAIL LIGHT GUARD USING # 8 x 3/4" SELF TAPPING SCREWS AND # 6 x 1/2" SCREWS PROVIDED DO NOT OVER TIGHTEN AND POSSIBLY STRIP THREADS.
- 6) RE-PEAT STEPS 1 THROUGH 6 ON THE DRIVER SIDE.

**CUSTOMER SERVICE TOLL FREE (888) 261-4537**