

STEELCRAFT

INSTALLATION INSTRUCTIONS
TAILLIGHT GUARD PART # 32160
2006 JEEP COMMANDER

PARTS LIST

- (1)- TAILLIGHT GUARD PASSENGER SIDE
- (1)- TAILLIGHT GUARD DRIVER SIDE
- (2)- SUPPORT BRACKETS
- (2)- # 6 x 1/2" SCREWS

INSTALLING TAILLIGHT GUARD

- 1) START WITH THE DRIVER SIDE, OPEN THE REAR LIFT GATE AND REMOVE THE PLASTIC CLIPS SECURING THE TAIL LIGHT TO THE BODY.
- 2) CAREFULLY UNSNAP THE TAIL LIGHT UNTIL IT IS FREED FROM THE HOUSING.
- 3) REMOVE THE TOP ATTACHMENT PIN FROM THE TAIL LIGHT. POSITION THE SUPPORT BRACKET BETWEEN THE PIN AND TAIL LIGHT (LARGER HOLE)
- 4) SNAP THE ASSEMBLY BACK INTO BODY.
- 5) POSITION TAILLIGHT GUARD OVER TAIL LIGHT, MAKING SURE THAT THE MOUNTING BRACKETS ON THE TAILLIGHT GUARD ARE SEATED WHERE THE TAIL LIGHT PLASTIC CLIPS WERE FORMERLY LOCATED.
- 6) SECURE ASSEMBLY TO JAMB USING THE PLASTIC CLIPS PREVIOUSLY REMOVED, SUPPORT BRACKET USE THE # 6 x 1/2" SCREWS.
- 6) RE-PEAT STEPS 1 THROUGH 6 ON THE PASSENGER SIDE.

CUSTOMER SERVICE TOLL FREE (888) 261-4537