

INSTALLATION INSTRUCTION

PART #:

REAR BUMPER GUARD FOR NISSAN MURANO 03-06

PARTS LIST:

- 1) REAR BUMPER GUARD
- 2) FRAME BRACKETS (ONE DRIVER, ONE PASSENGER SIDE)
- 4) 12MMX30MM FINE BOLTS
- 4) 1/2"X1-1/2" BOLTS
- 8) 1/2" FLAT WASHERS
- 4) 7/16" FLAT WASHERS
- 4) 1/2" LOCK NUTS

PROCEDURES:

1. LOCATE REAR TOW LOOP ON DRIVER SIDE AND REMOVE. TOW LOOP IS LOCATED ABOVE FACTORY EXHAUST PIPES. THE THREADED HOLES IN BODY PAN WILL BE THE MOUNTING LOCATION FOR THE DRIVER SIDE FRAME BRACKET.
2. FASTEN DRIVER SIDE BRACKET USING (2) 12MMX30MM BOLTS AND (2) 7/16" FLAT WASHERS TIGHTEN UNTIL SLIGHTLY SNUG.
3. REPEAT PROCESS FOR PASSENGER SIDE BRACKET. PASSENGER SIDE HOLES ARE LOCATED IN THE SAME CORRESPONDING LOCATION AS THE DRIVER SIDE.
4. RAISE GUARD TO BRACKETS AND FASTEN GUARD USING (2) 1/2"X1-1/2" BOLTS (4) 1/2" FLAT WASHERS AND (2) 1/2" LOCKNUTS PER SIDE TIGHTEN UNTIL SLIGHTLY SNUG. NOTE : GUARD SHOULD BE ON THE OUTSIDE OF THE FRAME BRACKETS.
5. ADJUST GUARD TO SATISFACTION AND TIGHTEN FRAME BOLTS , FOLLOWED BY ALL REAR BUMPER GUARD HARDWARE TO COMPLETE INSTALLATION

